

Netcomm NB16WV – Getting Started

These guides will walk you through setting up your new modem router for use on Adam Internet's ADSL, NBN, WiMAX or Fibre services.



ADSL Connections

1. Connect the power supply to the modem and plug it into a power point.
2. Connect the yellow Ethernet cable from port 1 on the modem to the Ethernet port on the back of your computer.
3. Connect the grey telephone cable to the ADSL port on the modem and plug the other end into your telephone wall socket.
4. Turn on the modem, wait 60 seconds for it to power up.
5. Adam Internet will attempt to remotely configure your settings, please wait 10 minutes before proceeding to the next step.
6. On your computer, open a web browser and enter www.adam.com.au/first.
7. Follow the instructions on the website to complete your setup.

Ethernet (NBN, WiMAX, Fibre) Connections

1. Connect the power supply to the modem and plug it into a power point.
2. Connect the yellow Ethernet cable from port 1 on the modem to the Ethernet port on the back of your computer.
3. Connect the other yellow Ethernet cable to the WAN port on the modem and depending on your service type, either:
 - For NBN connect the other end of the Ethernet cable into the NBN data port.
 - For WiMAX connect the other end in into the Ethernet port of the Power over Ethernet (PoE).
 - For Fibre connect the other end of the Ethernet cable in the wall data socket.
4. Turn on the modem, wait 60 seconds for it to power up.
5. Adam Internet will attempt to remotely configure your settings, please wait 10 minutes before proceeding to the next step.
6. On your computer, open a web browser and enter www.adam.com.au/first.
7. Follow the instructions on the website to complete your setup.

Unable To Get Online?

If after following the instructions above you are not able to connect to the internet, please give us a call on (08) 8423 4000.